



PORSCHE

Inspection (B markets*)

Macan

as of 2019 model

Name

Date

Licence No.

Mileage

Vehicle Ident. No.

Order No.:

Inspection

at 30000, 60000, 90000, 120000 km/20000, 40000, 60000, 80000 miles etc.

(For descriptions of the individual maintenance tasks, see: PCSS - Porsche Central Service System -> Information media -> Workshop Manual)

Note

If the mileage for an inspection is not reached, an inspection must be carried out every 2 years at the latest.

The term 'checking' includes all necessary subsequent work, such as adjustments, readjustments, corrections and topping up, but does not include repairs, replacements or overhaul of parts or assemblies.

Measures

			Macan	Every 30 tkm/20 tmls or 2 years				
	Electrics	Windscreen wiper/washer system, headlight cleaning system: check function and nozzle settings Horn: check function Tyres: check tyre pressure (TPM) Diagnostic system: read out fault memory and transfer gear wear integrator; reset maintenance interval Emergency call system (ERA-GLONASS, EVAK, ERA-RB): Check battery condition (Eurasian Customs Union only)	● ● ● ● ●	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	Every 45 tkm/30 tmls or 4 years Every 60 tkm/40 tmls or 4 years Every 120 tkm/80 tmls or 4 years Every 240 tkm/160 tmls or 16 years Time-dependent			
	Inside the vehicle	Particle filter: replace filter element Seat belts: check function and condition	● ●	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	
	Outside the vehicle	Check wiper blades All headlights: check adjustment Tyres and spare wheel: check condition Brake system: check brake pads and brake discs for wear (without removing wheels) Brake system: check brake pads and brake discs for wear Trailer hitch: check function	● ● ● ● ●	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	

* For country allocation, see overview of A, B and C markets

Carry out depending on mileage/age (Please tick)

Relevant model line

OK (one click) Not OK (double-click) Repaired (triple-click)

Copyright by
Dr. Ing. h. c. F. Porsche AG
Vertrieb After Sales Technik 02/21



Inspection (B markets*)

Macan

as of 2019 model

Measures		Macan	Every 30 tkm/20 tmls or 2 years	Every 45 tkm/30 tmls or 4 years	Every 60 tkm/40 tmls or 4 years	Every 120 tkm/80 tmls or 4 years	Every 240 tkm/160 tmls or 16 years	Time-dependent
	Outside the vehicle	Lubricate door arrester and fastening bolts	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Radiators and air intakes: visual inspection for external contamination and blockage	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Under the vehicle	Underbody panels: visual inspection for completeness, secure installation and damage	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Drain engine oil	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Visual inspection for leaks from underneath (oils and other fluids)	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Brake lines: visual inspection for damage, routing and corrosion	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Brake hoses: visual inspection for damage	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Drive shafts: visual inspection of the boots for leaks and damage	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Cardan shaft: visual inspection of the rubber bellows for damage	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Steering gear: visual inspection of the bellows for damage	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Tie rod joints: check play and dust bellows	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Axle joints: check the play and visually inspect the dust boots for damage	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Exhaust system: Visual inspection for leaks and damage, check brackets	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		PDK transmission: change clutch fluid (ATF) and filter	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		All-wheel final drive: change oil	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Rear final drive: change oil	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Engine compartment	Fill in engine oil	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Change oil filter	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on the season, use Porsche approved windscreen cleaner only	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Coolant: check level and antifreeze	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Check drive belt (only if vehicle is used for off-road driving)	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Visual inspection for leaks from above (oils and other fluids)	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		Fuel lines and connections: visual inspection	<input checked="" type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

* For country allocation, see overview of A, B and C markets

Carry out depending on mileage/age (Please tick)

- Relevant model line

OK (one click) Not OK (double-click) Repaired (triple-click)

Copyright by
Dr. Ing. h. c. F. Porsche AG
Vertrieb After Sales Technik 02/21



PORSCHE

Inspection (B markets*)

Macan

as of 2019 model

Measures		Macan	Every 30 tkm/20 tmls or 2 years	Every 45 tkm/30 tmls or 4 years	Every 60 tkm/40 tmls or 4 years	Every 120 tkm/80 tmls or 4 years	Every 240 tkm/160 tmls or 16 years	Time-dependent
	Engine compartment	Replace spark plugs Air cleaner: replace filter element	● ●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	Additional work every 2 years	Change brake fluid (use only original Porsche brake fluid) Prepare condition report for long-life guarantee Tyre sealing compound: check use-by date and replace if necessary	● ● ●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Test drive	Remote control, front seats, electric parking brake and footbrake, engine, transmission, steering, ParkAssist, cruise control, PSM switch, heating, sports exhaust system, air conditioning and instruments: check function Oils, fluids: visual inspection for leaks	● ●	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Signature (mechanic): _____

Stamp Porsche Centre

* For country allocation, see overview of A, B and C markets

Carry out depending on mileage/age (Please tick)

● Relevant model line

OK (one click) Not OK (double-click) Repaired (triple-click)